Pairing with a Bluetooth device

1. Scan "Start Configuration"

||||||||||||||||||||||||||||||||||

2. Scan "Open HID Connection"

||||||||||||||||||||||||||||||||||

3. Scan "Disconnect Previous Pairing"

||||||||||||||||||||

4. Scan "Enable BT Visibility"

||||||||||||||||||||||||

5. Scan "Save BT HID Configuration"

||||||||||||||||||||||||||||||||||

6. Scan "End BT HID Configuration"

||||||||||||||||||||||||||||||||||

7. Open up the Bluetooth settings on your device and search for available connections.

8. Select the "NVC_MD_CS45" to pair with the scanner.

NOTE: Most iOS applications will need a slower transmission speed to properly function. Use the configuration below to enable iOS Transmission speeds.

Enable iOS Transmission Speed

||||||||||||||||||||||||

*Disable iOS Transmission Speed

||||||||||||||||||||||||||||||

Enabling on screen keyboard with mobile devices

When using this scanner with iOS and Android devices the on-screen keyboard will no longer show. If the on-screen keyboard is still necessary use the directions below to enable it.

iOS

Scan the "Toggle iOS Keyboard Emulation" barcode below.

Android

On your Android device open up "Settings", "Languages & Input". Next choose "Physical Keyboard" and then turn on "Show virtual keyboard".

NOTE: Exact settings and directions may differ based on your Android device and version. Please contact your Android device manufacture for exact directions.